

# FOAMTAK™

STUDIOFOAM SPRAY ADHESIVE

---

Hey – thanks for buying the new & improved version of Auralex® Foamtak™ Spray Adhesive! Please follow all the directions and precautions printed on our can.

## Installation Tips:

Depending on how strong you want Foamtak to bond to the mounting surface, you can either spray your acoustic foam or the wall or both and can either stick your acoustic foam into place immediately or let it “cure” for up to 2 minutes. Spraying both the foam and the mounting surface, then letting the Foamtak cure for about 1 minute before sticking the foam into place, provides the strongest long-term bond and is the recommended method when mounting Venus Bass Traps, LENRDs and in some cases 4” Studiofoam. You don’t have to spray the back of each piece of foam entirely for Foamtak to work (*especially with thinner foam*), but, naturally, the more Foamtak you apply, the better adhesion you’ll achieve. Begin spraying in the center of the foam, then work out toward the edges, being careful not to get within ½” or so of the edges to minimize over spray getting on part of the foam where it might show.

Again, thank you for choosing Auralex Acoustics, Inc.. We really appreciate having you as our customer!

If you need any further acoustics help, please visit our website at [www.auralex.com](http://www.auralex.com) or call us at 800-95-WEDGE!

